

BlockMaster - T&B Cross Reference

T & B Series	BlockMaster P/N
3	HD61X-XX
4	DT39-BXXW-XX
4	HD83X-XX
6	DT49-BXXW-XX
6	HB95X-XX
25EV	25EV-XXP
2EEA	MSMXX045
2EHDR	CIMXX9P5
2EHDV	CIMXX0P5
2ESDV	CIFXX005
2LEEV	PSMXX0D5
2MR	DGWWG10R5-XX-ON
2MV	DGWWG10V5-XX-ON
4DB	DT31-B01W-XX
4DB	DT35-BXXW-XX
4DB	HD81X-XX
5KEV	MSGXX001
5LEA	MSMXX041
5LEEV	PSMXX0D1
5LEEV	PSMXX0D2
5MDV	DGPBP111-XX-ON
5MDV	DGPBH124V1-XX-ON
5ULV	DGWWG126V1-XX-ON
5ULVR	DGWWG126R1-XX-ON
B01T3H	DGWWG84R8-XX-ON
B01T3V	DGWWG84V8-XX-ON
B01T7H	DGWWG84R3-XX-ON
B01T7V	DGWWG84V3-XX-ON
B01W3H	MTSXX098
B01W3H	DGWWG84R8-XX-ON
B01W3V	MTSXX008
B01W3V	DGWWG84V8-XX-ON
B02C4V	MSGXX001
B02C5V	MSGXX002
B02T4H	DGWWG10R1-XX-ON
B02T4V	DGWWG10V1-XX-ON
B02T5H	DGWWG10R2-XX-ON
B02T5V	DGWWG10V2-XX-ON
B02W4H	DGWWG10R1-XX-ON
B02W4V	DGWWG10V1-XX-ON
B02W5H	DGWWG10V2-XX-ON
B02W5V	DGWWG10R2-XX-ON
B03C4H	MSQXX091
B03C4V	MSQXX001
B03C5H	MSQXX092
B03C5V	MSQXX002
B03W4H	DGWWG126R1-XX-ON
B03W4V	DGWWG126V1-XX-ON
B03W5H	DGWWG126R2-XX-ON

T & B Series	BlockMaster P/N
B03W5V	DGWWG126V2-XX-ON
B04C4V	DGWWG125A1-XX-ON
B04C5V	DGWWG125A2-XX-ON
B07C4V	PSMXX0D1
B07C5V	PSMXX0D2
B52C3U	CTFXX008
B52C4U	CIFXX001
B52C5U	CIFXX002
B71N4V	DGPBH124V1-XX-ON
B71N5V	DGPBH124V2-XX-ON
B72N4H	CIMXX9A1
B72N4V	CIMXX0A1
B72N5H	CIMXX9A2
B72N5V	CIMXX0A2
B73N3H	CTMXX9P8
B73N3V	CTMXX0P8
B73N4H	CIMXX9P1
B73N4V	CIMXX0P1
B73N5H	CIMXX9P2
B73N5V	CIMXX0P2
JC6	DT45-BXXW-XX
JC6	HI20X-XX
RSB2	HD61X-XX
RSB3	DT39-BXXW-XX
RSB3	HD83X-XX
RSB6	DT49-BXXW-XX
RSB6	HB95X-XX
SSB3	DT31-B01W-XX
SSB3	DT35-BXXW-XX
SSB3	HD81X-XX
SSB6	DT45-BXXW-XX
SSB6	HI20X-XX
TSB1000	PA12DS/XX
TSB230	PA08DS/XX
TSB500	PA10DS/XX